



7/27/2015

2016+ RZR TURBO BOOST RECIRCULATION VALVE KIT

READ THROUGH ALL INSTRUCTIONS PRIOR TO BEGINNING THIS INSTALLATION

PARTS LIST:

(1) EVO BRV

(2) 20-32MM HOSE CLAMPS

(1) 10MM PINCH CLAMP

- REMOVE REAR ACCESS PANEL TO THE TOP OF THE ENGINE
- USING A DYKES, REMOVE OEM CLAMPS THAT SECURE THE FACTORY DIVERTER VALVE TO THE CHARGE TUBE & RECIRCULATION HOSE – DO NOT DAMAGE THE OEM PORT/HOSE
- DISCARD CLAMPS
- REMOVE OEM BOV FROM THE CHARGE TUBES AND RECIRCULATION HOSE. CAREFULLY REMOVE THE CLAMP – DO NOT DAMAGE THE VACUUM HOSE! REMOVE HOSE FROM OEM BOV.
- INSTALL THE VACUUM HOSE ONTO THE EVOPS BOV AND SECURE THE HOSE WITH THE SUPPLIED 10MM PINCH CLAMP. INSTALL THE EVO BOV INTO THE CHARGE TUBE AND RECIRCULATION HOSE IN THE SAME ORIENTATION AS THE OEM BOV. SEE PICTURE BELOW.
- ONCE THE EVOPS BOV IS SEATED ALL THE WAY INTO THE RESPECTIVE PORT/HOSE, AND THERE IS CLEARANCE BETWEEN THE COIL PACK AND THE BOV, TIGHTEN WORM DRIVE CLAMPS.



Arizona

Manufacturing | Design

1625 E Weber Dr. | Tempe, AZ 85281
480.317.9911

www.evoms.com | www.evomsit.com

Colorado

Mountain Testing

30975 Hummingbird Lane
Steamboat Springs, CO 80487

www.evopowersports.com

Minnesota

Research | Development

2007 State Rd 35 | Somerset WI 54025
970-680-EVO1

jim@evopowersports.com